




A company of SIM Tech

## SIM900\_Email\_AT Command Manual\_V1.02



<b>Document Title:</b>	SIM900 Email AT Command Manual
<b>Version:</b>	1.02
<b>Date:</b>	2011-11-02
<b>Status:</b>	
<b>Document Control ID:</b>	SIM900_Email_ATC_V1.02

### **General Notes**

SIMCom offers this information as a service to its customers, to support application and engineering efforts that use the products designed by SIMCom. The information provided is based upon requirements specifically provided to SIMCom by the customers. SIMCom has not undertaken any independent search for additional relevant information, including any information that may be in the customer's possession. Furthermore, system validation of this product designed by SIMCom within a larger electronic system remains the responsibility of the customer or the customer's system integrator. All specifications supplied herein are subject to change.

### **Copyright**

This document contains proprietary technical information which is the property of SIMCom Limited., copying of this document and giving it to others and the using or communication of the contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages. All rights reserved in the event of grant of a patent or the registration of a utility model or design. All specification supplied herein are subject to change without notice at any time.

*Copyright © Shanghai SIMCom Wireless Solutions Ltd. 2011*

## Version History

Version	Chapter	What is new
V1.00	Origin	
V1.01	2.9 AT+SMTPFILE 2.11 AT+SMTPFT	Added new command Added new command
V1.02	2.12 AT+SMTPCS	Added new command

## Contents

Version History .....	2
1 Introduction .....	4
1.1 Features .....	4
1.2 Reference .....	4
1.3 Glossary .....	4
2 AT commands .....	5
2.1 AT+EMAILCID .....	5
2.2 AT+EMAILTO .....	5
2.3 AT+SMTPSRV .....	6
2.4 AT+SMTPAUTH .....	7
2.5 AT+SMTPFROM .....	8
2.6 AT+SMTPRCPT .....	8
2.7 AT+SMTPSUB .....	9
2.8 AT+SMTPBODY .....	10
2.9 AT+SMTPFILE .....	11
2.10 AT+SMTPSEND .....	11
2.11 AT+SMTPFT .....	12
2.12 AT+SMTPCS .....	13
2.13 AT+POP3SRV .....	14
2.14 AT+POP3IN .....	15
2.15 AT+POP3NUM .....	16
2.16 AT+POP3LIST .....	16
2.17 AT+POP3UIDL .....	17
2.18 AT+POP3CMD .....	18
2.19 AT+POP3READ .....	20
2.20 AT+POP3DEL .....	21
2.21 AT+POP3RSET .....	22
2.22 AT+POP3OUT .....	22
3 Examples .....	24
3.1 Bearer profile .....	24
3.2 Send an Email .....	24
3.3 Send an Email with an attachment .....	25
3.4 Send a UTF-8 Email .....	26
3.5 Retrieve the Email .....	27
3.6 Delete the Email .....	28
3.7 Get the Email's size and unique-id .....	28

## 1 Introduction

This document presents the AT command of Email operation for SIM900. This document can apply to the same series of the modules which contain Email function, like SIM900, SIM900D, SIM900B and SIM900A.

### 1.1 Features

1. SIM900 supports to send an Email with an attachment via SMTP protocol. It also supports carbon copy (abbreviated Cc:) recipient and blind carbon copy (abbreviated Bcc:) recipient.
2. SIM900 supports to retrieve and delete the Email via POP3 protocol, the Email may be with attachments.
3. SIM900 supports all of POP3 commands but APOP. By these POP3 commands, you can get the specific Email's size and unique-id.
4. SIM900 does not support that SMTP and POP3 operations are executed at the same time.

### 1.2 Reference

- [1] SIM900 AT Commands Set
- [2] SIM900\_TCPIP

### 1.3 Glossary

<b>GPRS</b>	General Packet Radio Service
<b>IP</b>	Internet Protocol
<b>EMAIL</b>	Electronic Mail
<b>SMTP</b>	Simple Mail Transfer Protocol
<b>POP3</b>	Post Office Protocol 3

## 2 AT commands

### 2.1 AT+EMAILCID

<b>AT+EMAILCID</b> Set Email Bearer Profile Identifier	
Test Command <b>AT+EMAILCID=?</b>	Response +EMAILCID: (range of supported <cid>s)  <b>OK</b>  Parameters See Write Command
Read Command <b>AT+EMAILCID?</b>	Response +EMAILCID: <cid>  <b>OK</b>  Parameters See Write Command
Write Command <b>AT+EMAILCID=&lt;cid&gt;</b>	Response  <b>OK</b> If error is related to ME functionality: <b>ERROR</b> Parameters <cid> bearer profile identifier refer to AT+SAPBR
Reference	Note

### 2.2 AT+EMAILTO

<b>AT+EMAILTO</b> Set Timeout Value of SMTP/POP3 Server Response	
Test Command <b>AT+EMAILTO=?</b>	Response +EMAILTO: (range of supported <timeout>s)  <b>OK</b>  Parameter See Write Command
Read Command <b>AT+EMAILTO?</b>	Response +EMAILTO: <timeout>

	<p><b>OK</b></p> <p>Parameter</p> <p>See Write Command</p>
Write Command <b>AT+EMAILTO=</b> <b>&lt;timeout&gt;</b>	<p>Response</p> <p><b>OK</b></p> <p>If error is related to ME functionality:</p> <p><b>ERROR</b></p> <p>Parameter</p> <p><b>&lt;timeout&gt;</b> The timeout value of SMTP/POP3 server response, in 1 second unit.</p> <p>10-120 Default: 30(seconds)</p>
Reference	Note

### 2.3 AT+SMTPSRV

<b>AT+SMTPSRV</b> Set SMTP Server Address and Port	
Test Command <b>AT+SMTPSRV=?</b>	<p>Response</p> <p>+SMTPSRV: &lt;smtpServerLength&gt;,(range of supported &lt;smtpPort&gt;s)</p> <p><b>OK</b></p> <p>Parameter</p> <p>See Write Command</p>
Read Command <b>AT+SMTPSRV?</b>	<p>Response</p> <p>+SMTPSRV: &lt;smtpServer&gt;,&lt;smtpPort&gt;</p> <p><b>OK</b></p> <p>Parameter</p> <p>See Write Command</p>
Write Command <b>AT+SMTPSRV=</b> <b>&lt;smtpServer&gt;[,&lt;sm</b> <b>tpPort&gt;]</b>	<p>Response</p> <p><b>OK</b></p> <p>If error is related to ME functionality:</p> <p><b>ERROR</b></p> <p>Parameter</p> <p><b>&lt;smtpServer&gt;</b> SMTP server address, string type. This parameter can be either:</p> <ul style="list-style-type: none"> <li>- IP address in the format: xxx.xxx.xxx.xxx</li> <li>- Host name to be solved with a DNS query</li> </ul>

	<p><b>&lt;smtpPort&gt;</b> The SMTP port 1-65535 Default: 25</p> <p><b>&lt;smtpServerLength&gt;</b> The max length of &lt;smtpServer&gt;</p>
Reference	Note

## 2.4 AT+SMTPAUTH

<b>AT+SMTPAUTH</b> Set User Name and Password for SMTP Authentication	
Test Command <b>AT+SMTPAUTH=?</b>	<p>Response <b>+SMTPAUTH:</b> (range of supported&lt;authType&gt;s),&lt;userNameLength&gt;,&lt;passwordLength&gt;</p> <p><b>OK</b></p> <p>Parameter See Write Command</p>
Read Command <b>AT+SMTPAUTH?</b>	<p>Response <b>+SMTPAUTH:</b> &lt;authType&gt;,&lt;username&gt;,&lt;password&gt;</p> <p><b>OK</b></p> <p>Parameter See Write Command</p>
Write Command <b>AT+SMTPAUTH=&lt;authType&gt;[,&lt;userName&gt;,&lt;password&gt;]</b>	<p>Response</p> <p><b>OK</b></p> <p>If error is related to ME functionality: <b>ERROR</b></p> <p>Parameter</p> <p><b>&lt;authType&gt;</b> The type of SMTP authentication</p> <ul style="list-style-type: none"> <li>0 SMTP server does not request authentication. &lt;username&gt; and &lt;password&gt; must not be given.</li> <li>1 SMTP server requests authentication</li> </ul> <p><b>&lt;userName&gt;</b> The user name for SMTP authentication.</p> <p><b>&lt;userNameLength&gt;</b> The max length of &lt;userName&gt;.</p> <p><b>&lt;password&gt;</b> The password for SMTP authentication.</p> <p><b>&lt;passwordLength&gt;</b> The max length of &lt;password&gt;.</p>
Reference	Note

## 2.5 AT+SMTPFROM

<b>AT+SMTPFROM</b> Set Sender Address and Name	
Test Command <b>AT+SMTPFROM=?</b>	Response <b>+SMTPFROM: &lt;senderAddressLength&gt;,&lt;senderNameLength&gt;</b>  <b>OK</b>
	Parameter See Write Command
Read Command <b>AT+SMTPFROM?</b>	Response <b>+SMTPFROM: &lt;senderAddress&gt;,&lt;senderName&gt;</b>  <b>OK</b>
	Parameter See Write Command
Write Command <b>AT+SMTPFROM=&lt;senderAddress&gt;[,&lt;senderName&gt;]</b>	Response  <b>OK</b> If error is related to ME functionality: <b>ERROR</b> Parameter <b>&lt;senderAddress&gt;</b> The Email sender address,string type. <b>&lt;senderAddressLength&gt;</b> The max length of <senderAddress> <b>&lt;senderName&gt;</b> The Email sender name,string type. <b>&lt;senderNameLength&gt;</b> The max length of <senderName>
Reference	Note

## 2.6 AT+SMTPRCPT

<b>AT+SMTPRCPT</b> Set the Email Recipient(TO/CC/BCC) Address and Name	
Test Command <b>AT+SMTPRCPT=?</b>	Response <b>+SMTPRCPT: (range of supported &lt;rcptType&gt;s),(range of supported &lt;index&gt;s),&lt;rcptAddressLength&gt;,&lt;rcptNameLength&gt;</b>  <b>OK</b>
	Parameter See Write Command

Read Command <b>AT+SMTPRCPT?</b>	Response [+SMTPRCPT: <rcptType>,<index>,<rcptAddress>,<rcptName> <CR><LF>+SMTPRCPT: <rcptType>,<index>,<rcptAddress>,<rcptName>[...]]  <b>OK</b>
Write Command <b>AT+SMTPRCPT=</b> <b>&lt;rcptType&gt;</b> [,<index> [,<rcptAddress> [,<rcptName>]]]	Response  <b>OK</b> If error is related to ME functionality: <b>ERROR</b>  Parameter  <b>&lt;rcptType&gt;</b> The type of recipient, the types of TO and CC are used to construct e-mail header in the field:"To:" or "Cc:". 0 TO, Normal Recipient. 1 CC, Carbon Copy recipient. 2 BCC, Blind Carbon Copy recipient. <b>&lt;index&gt;</b> Index of the type of recipient, decimal format <b>&lt;rcptAddress&gt;</b> The Email recipient address. <b>&lt;rcptName&gt;</b> The Email recipient name. <b>&lt;rcptAddressLength&gt;</b> The max length of <rcptAddress>. <b>&lt;rcptNameLength&gt;</b> The max length of <rcptName>.
Reference	Note <ul style="list-style-type: none"> <li>● If only &lt;rcptType&gt; is given,it will delete all items of &lt;rcptType&gt;</li> <li>● If only &lt;rcptType&gt; and &lt;index&gt; are given,it will delete the &lt;index&gt; item of &lt;rcptType&gt;.</li> </ul>

## 2.7 AT+SMTPSUB

<b>AT+SMTPSUB</b>	Set the Email Subject
Test Command <b>AT+SMTPSUB=?</b>	Response +SMTPSUB: <subjectLength>  <b>OK</b>
Read Command <b>AT+SMTPSUB?</b>	Response +SMTPSUB: <subject>

	<p><b>OK</b></p> <p>Parameter See Write Command</p>
Write Command <b>AT+SMTPSUB=</b> <b>&lt;subject&gt;</b>	<p>Response</p> <p><b>OK</b></p> <p>If error is related to ME functionality: <b>ERROR</b></p> <p>Parameter  <b>&lt;subject&gt;</b> The Email subject, string type. It will be present in the header of the Email sent by SMTP client in the field: "Subject:".   <b>&lt;subjectLength&gt;</b> The max length of &lt;subject&gt;.</p>
Reference	<p>Note</p> <ul style="list-style-type: none"> <li>● If the Email charset is not ASCII,&lt;subject&gt; must be in hexadecimal format.</li> </ul>

## 2.8 AT+SMTPBODY

<b>AT+SMTPBODY</b> Set the Email Body	
Test Command <b>AT+SMTPBODY=?</b>	<p>Response +SMTPBODY: &lt;bodyLength&gt;</p> <p><b>OK</b></p> <p>Parameter See Write Command</p>
Execution Command <b>AT+SMTPBODY=</b> response ">", then type data as Email body.tap CTRL+Z to save, tap ESC to cancel the operation	<p>Response</p> <p><b>OK</b></p> <p>If error is related to ME functionality: <b>ERROR</b></p> <p>Parameter  <b>&lt;bodyLength&gt;</b> The max length of Email body.</p>
Reference	<p>Note</p> <ul style="list-style-type: none"> <li>● If the Email charset is not ASCII, the body of Email must be in hexadecimal format.</li> </ul>

## 2.9 AT+SMTPFILE

<b>AT+SMTPFILE</b> Set the Email Attachment	
Test Command <b>AT+SMTPFILE=?</b>	<p>Response  <b>+SMTPFILE:</b> (range of &lt;fileType&gt;s),&lt;fileNameLength&gt;,(range of &lt;encodeType&gt;s)</p> <p><b>OK</b></p>
Read Command <b>AT+SMTPFILE?</b>	<p>Response  <b>+SMTPFILE:</b> &lt;fileType&gt;,&lt;fileName&gt;,&lt;encodeType&gt;</p> <p><b>OK</b></p>
Write Command <b>AT+SMTPFILE=</b> <fileType>[,<fileName>,<encodeType>]	<p>Response</p> <p><b>OK</b></p> <p>If error is related to ME functionality:  <b>ERROR</b></p> <p>Parameter</p> <p>&lt;fileType&gt; The type of the Email attachment.</p> <ul style="list-style-type: none"> <li>0 no attachment</li> <li>1 attach a txt file</li> <li>2 attach a binary file (bmp, mp3, video...)</li> </ul> <p>&lt;fileName&gt; The name of the Email attachment.</p> <p>&lt;fileNameLength&gt; The max length of &lt;fileName&gt;.</p> <p>&lt;encodeType&gt; Content-Transfer-Encoding used for attachment</p> <ul style="list-style-type: none"> <li>0 “7bit” means data all represented as short lines of US-ASCII data</li> <li>1 “base64” designed to represent arbitrary sequences of octets in a form that need not be humanly readable</li> </ul>
Reference	<p>Note</p> <ul style="list-style-type: none"> <li>● If a txt file (&lt;fileType&gt;=1) is attached, &lt;encodeType&gt; must be 0.</li> <li>● If a binary file (&lt;fileType&gt;=2) is attached, &lt;encodeType&gt; must be 1.</li> </ul>

## 2.10 AT+SMTPSEND

<b>AT+SMTPSEND</b> Send the Email	
SIM900_Email_AT Command Manual_V1.02	11

Test Command <b>AT+SMTPSEND=?</b>	Response  <b>OK</b> Parameter
Write Command <b>AT+SMTPSEND</b>	Response  <b>OK</b> If error is related to ME functionality: <b>ERROR</b> If send successfully or not, return: <b>+SMTPSEND: &lt;code&gt;</b>  Parameter  <b>&lt;code&gt;</b> The result of sending Email. 1      The Email has been sent successfully. 61     Network error. 62     DNS resolve error 63     SMTP TCP connection error. 64     Timeout of SMTP server response 65     SMTP server response error 66     Not authentication 67     Authentication failed. SMTP user name or password may be not right. 68     Bad recipient.
Reference	Note

## 2.11 AT+SMTPFT

AT+SMTPFT	Transfer the Email Attachment
Test Command <b>AT+SMTPFT=?</b>	Response  <b>OK</b> Parameter See Write Command
Execution Command <b>AT+SMTPFT=&lt;reqLength&gt;</b>	Response When the URC below is reported, the attachment can be transferred: <b>+SMTPFT: 1,&lt;maxLength&gt;</b>  If <b>&lt;reqLength&gt;</b> is not 0 and send data successfully: <b>+SMTPFT: 2,&lt;cnfLength&gt;</b> .....                    //Input data

	<p><b>OK</b></p> <p>If &lt;reqLength&gt; is not 0 and send data unsuccessfully:  <b>+SMTPFT: 2,&lt;cnfLength&gt;</b>  ..... //Input data</p> <p><b>ERROR</b></p> <p>If &lt;reqLength&gt; is 0,it indicates that transferring the attachment have finished:</p> <p><b>OK</b></p> <p>If error is related to ME functionality:  <b>ERROR</b></p> <p>If some error occur:  <b>+SMTPSEND: &lt;code&gt;</b></p>
Reference	<p>Parameter</p> <p>&lt;reqLength&gt; Requested number of data bytes(0-&lt;maxLength&gt;) to be transmitted</p> <p>&lt;cnfLength&gt; Confirmed number of data bytes to be transmitted</p> <p>&lt;maxLength&gt; The max length of data can be sent at a time. It depends on the network status.</p> <p>&lt;code&gt; See AT+SMTPSEND</p>

## 2.12 AT+SMTPCS

AT+SMTPCS	Set the Email Charset
Test Command <b>AT+SMTPCS=?</b>	<p>Response</p> <p><b>+SMTPCS: &lt;charsetLength&gt;</b></p> <p><b>OK</b></p> <p>Parameter</p> <p>See Write Command</p>
Read Command <b>AT+SMTPCS?</b>	<p>Response</p> <p><b>+SMTPCS: &lt;charset&gt;</b></p> <p><b>OK</b></p>

	<p>Parameter See Write Command</p>
Write Command <b>AT+SMTPCS=</b> <b>&lt;charset&gt;</b>	<p>Response</p> <p><b>OK</b></p> <p>If error is related to ME functionality: <b>ERROR</b></p>
	<p>Parameter <b>&lt;charset&gt;</b> The Email charset, string type. It shows which charset the subject and the body are encoded in. If &lt; charset &gt; is not ASCII but UTF-8 or other, the subject and the body must be in hexadecimal format (e.g. "TEST" should be converted to "54455354"). The default charset is ASCII. <b>&lt;charsetLength&gt;</b> The max length of &lt; charset &gt;.</p>
Reference	Note

## 2.13 AT+POP3SRV

<b>AT+POP3SRV</b> Set POP3 Server and Account	
Test Command <b>AT+POP3SRV=?</b>	<p>Response <b>+POP3SRV: &lt;pop3ServerLength&gt;,&lt;userNameLength&gt;,&lt;passwordLength&gt;, (range of supported &lt;pop3Port&gt;s)</b></p> <p><b>OK</b></p>
	<p>Parameter See Write Command</p>
Read Command <b>AT+POP3SRV?</b>	<p>Response <b>+POP3SRV: &lt;pop3Server&gt;,&lt;userName&gt;,&lt;password&gt;,&lt;pop3Port&gt;</b></p> <p><b>OK</b></p>
	<p>Parameter See Write Command</p>
Write Command <b>AT+POP3SRV=</b> <b>&lt;pop3Server&gt;,&lt;userName&gt;,&lt;password&gt;</b> <b>[,&lt;pop3Port&gt;]</b>	<p>Response</p> <p><b>OK</b></p> <p>If error is related to ME functionality: <b>ERROR</b></p>
	<p>Parameter <b>&lt;pop3Server&gt;</b> POP3 server address, string type. This parameter can be either:</p>

	<ul style="list-style-type: none"> <li>- IP address in the format: xxx.xxx.xxx.xxx</li> <li>- Host name to be solved with a DNS query</li> </ul> <p><b>&lt;userName&gt;</b> The user name to log in POP3 server, string type.</p> <p><b>&lt;password&gt;</b> The password to log in POP3 server, string type.</p> <p><b>&lt;pop3Port&gt;</b> The port of POP3 server. 1-65535 Default: 110</p> <p><b>&lt;pop3ServerLength&gt;</b> The max length of &lt;pop3Server&gt;.</p> <p><b>&lt;userNameLength&gt;</b> The max length of &lt;userName&gt;.</p> <p><b>&lt;passwordLength&gt;</b> The max length of &lt;password&gt;.</p>
Reference	Note

## 2.14 AT+POP3IN

AT+POP3IN	Log In POP3 Server																		
Test Command <b>AT+POP3IN=?</b>	<p>Response</p> <p><b>OK</b></p> <p>Parameter</p>																		
Execution Command <b>AT+POP3IN</b>	<p>Response</p> <p><b>OK</b></p> <p>If error is related to ME functionality: <b>ERROR</b></p> <p>If logging in POP3 server or not, return: <b>+POP3IN: &lt;code&gt;</b></p> <p>Parameter</p> <p><b>&lt;code&gt;</b> The result of logging in POP3 server</p> <table> <tr> <td>1</td> <td>Log in POP3 server successfully</td> </tr> <tr> <td>61</td> <td>Network error</td> </tr> <tr> <td>62</td> <td>DNS resolve error</td> </tr> <tr> <td>63</td> <td>POP3 tcp connection error</td> </tr> <tr> <td>64</td> <td>Timeout of POP3 server response</td> </tr> <tr> <td>65</td> <td>POP3 server response error</td> </tr> <tr> <td>66</td> <td>POP3 server rejects to log in</td> </tr> <tr> <td>67</td> <td>Incorrect user name</td> </tr> <tr> <td>68</td> <td>Incorrect user name or password</td> </tr> </table>	1	Log in POP3 server successfully	61	Network error	62	DNS resolve error	63	POP3 tcp connection error	64	Timeout of POP3 server response	65	POP3 server response error	66	POP3 server rejects to log in	67	Incorrect user name	68	Incorrect user name or password
1	Log in POP3 server successfully																		
61	Network error																		
62	DNS resolve error																		
63	POP3 tcp connection error																		
64	Timeout of POP3 server response																		
65	POP3 server response error																		
66	POP3 server rejects to log in																		
67	Incorrect user name																		
68	Incorrect user name or password																		
Reference	Note																		

## 2.15 AT+POP3NUM

AT+POP3NUM      Get Email Number and Total Size	
Test Command <b>AT+POP3NUM=?</b>	Response  <b>OK</b> Parameter
Execution Command <b>AT+POP3NUM</b>	Response  <b>OK</b> If error is related to ME functionality: <b>ERROR</b> If POP3 server issues a positive response: <b>+POP3NUM: 1,&lt;totalNumber&gt;,&lt;totalSize&gt;</b> If POP3 server issues a negative response: <b>+POP3NUM: 0</b> If some error occur: <b>+POP3OUT: &lt;code&gt;</b> Parameter  <b>&lt;totalNumber&gt;</b> The Email number on the POP3 server, decimal format. <b>&lt;totalSize&gt;</b> The total size of all Email and the unit is in byte. <b>&lt;code&gt;</b> The result of logging out POP3 server 1       Normally log out POP3 server 61      Network error 62      DNS resolve error 63      POP3 tcp connection error 64      Timeout of POP3 server response
Reference	Note

## 2.16 AT+POP3LIST

AT+POP3LIST      Get the Specific Email Size	
Test Command <b>AT+POP3LIST=?</b>	Response  <b>+POP3LIST: (range of supported &lt;msgNumber&gt;s)</b>  <b>OK</b>
	Parameter See Write Command

Write Command <b>AT+POP3LIST=</b> <b>&lt;msgNumber&gt;</b>	<p>Response</p> <p><b>OK</b></p> <p>If error is related to ME functionality: <b>ERROR</b></p> <p>If POP3 server issues a positive response: <b>+POP3LIST: 1,&lt;msgNumber&gt;,&lt;size&gt;</b></p> <p>If POP3 server issues a negative response: <b>+POP3LIST: 0</b></p> <p>If some error occur: <b>+POP3OUT: &lt;code&gt;</b></p>										
	<p>Parameter</p> <p><b>&lt;msgNumber&gt;</b> The message number of Email.</p> <p><b>&lt;size&gt;</b> The size of Email <b>&lt;msgNumber&gt;</b> and the unit is in byte.</p> <p><b>&lt;code&gt;</b> The result of logging out POP3 server</p> <table style="margin-left: 20px;"> <tr><td>1</td><td>Normally log out POP3 server</td></tr> <tr><td>61</td><td>Network error</td></tr> <tr><td>62</td><td>DNS resolve error</td></tr> <tr><td>63</td><td>POP3 tcp connection error</td></tr> <tr><td>64</td><td>Timeout of POP3 server response</td></tr> </table>	1	Normally log out POP3 server	61	Network error	62	DNS resolve error	63	POP3 tcp connection error	64	Timeout of POP3 server response
1	Normally log out POP3 server										
61	Network error										
62	DNS resolve error										
63	POP3 tcp connection error										
64	Timeout of POP3 server response										
Reference	Note										

## 2.17 AT+POP3UIDL

<b>AT+POP3UIDL</b> Get the Specific Email Unique-id	
Test Command <b>AT+POP3UIDL=?</b>	<p>Response</p> <p><b>+POP3UIDL: (range of supported &lt;msgNumber&gt;s)</b></p> <p><b>OK</b></p>
Write Command <b>AT+POP3UIDL=</b> <b>&lt;msgNumber&gt;</b>	<p>Response</p> <p><b>OK</b></p> <p>If error is related to ME functionality: <b>ERROR</b></p> <p>If POP3 server issues a positive response: <b>+POP3UIDL: 1,&lt;msgNumber&gt;,&lt;uid&gt;</b></p> <p>If POP3 server issues a negative response: <b>+POP3UIDL: 0</b></p> <p>If some error occur:</p>

	<p><b>+POP3OUT: &lt;code&gt;</b></p> <p>Parameter</p> <p>&lt;msgNumber&gt; The message number of Email .</p> <p>&lt;UID&gt; The Email unique-id, the unique-id is an arbitrary server-determined string, consisting of 1 to 70 characters in the range 0x21 to 0x7E,which uniquely identifies a message within a maildrop and which persists across sessions.</p> <p>&lt;code&gt; The result of logging out POP3 server</p> <ul style="list-style-type: none"> <li>1 Normally log out POP3 server</li> <li>61 Network error</li> <li>62 DNS resolve error</li> <li>63 POP3 tcp connection error</li> <li>64 Timeout of POP3 server response</li> </ul>
Reference	Note

## 2.18 AT+POP3CMD

AT+POP3CMD	Get Multi-line Response
Test Command <b>AT+POP3CMD=?</b>	<p>Response</p> <p><b>+POP3CMD:</b> (range of supported &lt;cmdType&gt;s),(range of supported &lt;msgNumber&gt;s),(range of supported &lt;lineNumber&gt;s)</p> <p><b>OK</b></p> <p>Parameter</p> <p>See Write Command</p>
Write Command <b>AT+POP3CMD=</b> <cmdType> [,<msgNumber> [,lineNumber]]	<p>Response</p> <p><b>OK</b></p> <p>If error is related to ME functionality: <b>ERROR</b></p> <p>If POP3 server issues a positive response: <b>+POP3CMD: 1</b></p> <p>If POP3 server issues a negative response: <b>+POP3CMD: 0</b></p> <p>If some error occur: <b>+POP3OUT: &lt;code&gt;</b></p> <p>Parameter</p> <p>&lt;cmdType&gt; The values that supported POP3 user command</p> <ul style="list-style-type: none"> <li>1 List command</li> </ul> <p>The “List” command returns a multi-line “scan listing”. For each message on the maildrop list of the server the POP3</p>

service returns a line containing the message number and its size in bytes. A final “dotline” will be printed at the end of the “scan listing”. If there are no messages on the maillist of the server, the POP3 service returns a positive response, i.e. It does not issue an error response, but the “scan listing” will be empty. In either case, each scan listing will be finished by so-called “dotline”, i.e. a new line with just a single dot. <msgNumber> and <lineNumber> must not be given.

## 2 Uidl command

The “Uidl” command returns a multi-line “unique-id Listing”. For each message on the maillist of the Server the POP3 service returns a line containing the message number and its unique-id. A final “dotline” will be printed at the end of the “unique-id listing”. If there are no messages on the maillist of the server. The POP3 service returns a positive response, i.e. It does not issue an error response, but the “unique-id listing” will be empty. In either case, each unique-id listing will be finished by so-called “dotline”, i.e. a new line with just a singledot. <msgNumber> and <lineNumber> must not be given.

## 3 Top command

The command retrieves the number of lines of the message’s body from the POP3 server’s maillist. The POP3 server sends the headers of the message, the blank line separating the headers from the body, and then the number of lines of the message’s body. If the number of lines requested by The POP3 client is greater than the number of lines in the body, then the POP3 server sends the entire message. If no such message exists on the server the POP3 service issues an error response to the user. Each email will be finished by a so-called “dotline”, i.e. a new line with just a single dot. <msgNumber> and <lineNumber> must be given.

## 4 Retrieve command

The command retrieves the related message from the POP3 server’s maillist. If no such message exists on the server the POP3 service issues an error response to the user. Each email will be finished by a so-called “dotline”, i.e. a new line with just a single dot. <msgNumber> must be given.

**<msgNumber>** The message number of Email.

**<lineNumber>** The number of lines of the message body.

	<p><b>&lt;code&gt;</b> The result of logging out POP3 server</p> <ul style="list-style-type: none"> <li>1 Normally log out POP3 server</li> <li>61 Network error</li> <li>62 DNS resolve error</li> <li>63 POP3 tcp connection error</li> <li>64 Timeout of POP3 server response</li> </ul>
Reference	<p>Note</p> <ul style="list-style-type: none"> <li>● After sending these POP3 commands and POP3 server issuing a positive response, you can get the response by AT+POP3READ.</li> </ul>

## 2.19 AT+POP3READ

<b>AT+POP3READ</b> Read Multi-line Response	
Test Command	Response
<b>AT+POP3READ=?</b>	+POP3READ: (range of supported <reqLength>s)
	<b>OK</b>
	Parameter
	See Write Command
Write Command	Response
<b>AT+POP3READ=</b> <b>&lt;reqLength&gt;</b>	<p>If the data of response not to be read completely: +POP3READ: 1,&lt;cnfLength&gt;</p> <p>If the data of response to be read completely: +POP3READ: 2,&lt;cnfLength&gt;</p> <p>If some data need to be read, the URC below is reported: +POP3READ: 3,&lt;dataLength&gt;</p> <p>If error is related to ME functionality: <b>ERROR</b></p> <p>If some error occur: +POP3OUT: &lt;code&gt;</p> <p>Parameter</p> <p><b>&lt;reqLength&gt;</b> Requested number of data bytes (1-1460) to be read</p> <p><b>&lt;cnfLength&gt;</b> Confirmed number of data bytes to be read, which may be less than &lt;reqLength&gt;. 0 indicates that no data can be read.</p> <p><b>&lt;dataLength&gt;</b> Received number of data bytes.</p> <p><b>&lt;code&gt;</b> The result of logging out POP3 server</p> <ul style="list-style-type: none"> <li>1 Normally log out POP3 server</li> <li>61 Network error</li> <li>62 DNS resolve error</li> <li>63 POP3 tcp connection error</li> <li>64 Timeout of POP3 server response</li> </ul>

	69      Read data timeout	
Reference	<p>Note</p> <ul style="list-style-type: none"> <li>● Other AT commands (but AT+POP3OUT) can not be executed until the data of response are read completely.</li> <li>● If &lt;confLength&gt; is less than &lt;reqLength&gt;, you should wait for a URC “+POP3READ: 3,&lt;dataLength&gt;” reported. Then you may continue to read data by AT+POP3READ.</li> <li>● If the module has some unread data, the URC “+POP3READ: 3,&lt;dataLength&gt;” is reported every once in a while. After some time, these data are not still read, the module will quit the POP3 process.</li> </ul>	

## 2.20 AT+POP3DEL

<b>AT+POP3DEL</b>	<b>Mark the Specific Email to Delete</b>
Test Command <b>AT+POP3DEL=?</b>	Response <b>+POP3DEL:</b> (range of supported <msgNumber>s)  <b>OK</b>
Write Command <b>AT+POP3DEL=&lt;msgNumber&gt;</b>	Response  <b>OK</b> If error is related to ME functionality: <b>ERROR</b> If POP3 server issues a positive response: <b>+POP3DEL: 1</b> If POP3 server issues a negative response: <b>+POP3DEL: 0</b> If some error occur: <b>+POP3OUT: &lt;code&gt;</b>
Reference	Note <ul style="list-style-type: none"> <li>● The POP3 server marks the Email as deleted. Any future reference</li> </ul>

	to the message-number associated with the Email in a POP3 command generates an error. The POP3 server does not actually delete the Email until the POP3 client logs out POP3 server and closes the session normally.
--	--

## 2.21 AT+POP3RSET

AT+POP3RSET	Unmark the Emails that Be Marked as Deleted
Test Command <b>AT+POP3RSET=?</b>	Response  <b>OK</b> Parameter
Execution Command <b>AT+POP3RSET</b>	Response  <b>OK</b> If error is related to ME functionality: <b>ERROR</b> If POP3 server issues a positive response: <b>+POP3RSET: 1</b> If POP3 server issues a negative response: <b>+POP3REST: 0</b> If some error occur: <b>+POP3OUT: &lt;code&gt;</b> Parameter <code> The result of logging out POP3 server 1 Normally log out POP3 server 61 Network error 62 DNS resolve error 63 POP3 tcp connection error 64 Timeout of POP3 server response
Reference	Note

## 2.22 AT+POP3OUT

AT+POP3OUT	Log Out POP3 Server
Test Command <b>AT+POP3OUT=?</b>	Response  <b>OK</b>
	Parameter

Execution Command <b>AT+POP3OUT</b>	<p>Response</p> <p><b>OK</b></p> <p>If error is related to ME functionality:</p> <p><b>ERROR</b></p> <p>If the process is completed, return:</p> <p><b>+POP3OUT: &lt;code&gt;</b></p>										
	<p>Parameter</p> <p><b>&lt;code&gt;</b> The result of logging out POP3 server</p> <table> <tr><td>1</td><td>Normally log out POP3 server</td></tr> <tr><td>61</td><td>Network error</td></tr> <tr><td>62</td><td>DNS resolve error</td></tr> <tr><td>63</td><td>POP3 tcp connection error</td></tr> <tr><td>64</td><td>Timeout of POP3 server response</td></tr> </table>	1	Normally log out POP3 server	61	Network error	62	DNS resolve error	63	POP3 tcp connection error	64	Timeout of POP3 server response
1	Normally log out POP3 server										
61	Network error										
62	DNS resolve error										
63	POP3 tcp connection error										
64	Timeout of POP3 server response										
Reference	Note										

### 3 Examples

SIM900 module provides some AT commands that achieve the following function.

1. Send an Email without attachment via SMTP protocol.
2. Retrieve and delete the Email via POP3 protocol.
3. Get the specific Email's information (size and unique-id).

#### 3.1 Bearer profile

Demonstration	Syntax	Expert Results
Configure bearer profile 1	AT+SAPBR=3,1,"Contype","GPRS"	OK
	AT+SAPBR=3,1,"APN","CMNET"	OK
To open a GPRS context.	AT+SAPBR=1,1	OK
To query the GPRS context	AT+SAPBR=2,1	+SAPBR:1,1,"10.89.193.1"
		OK
To close a GPRS context.	AT+SAPBR=0,1	OK
GPRS context is released by network		+SAPBR 1: DEACT

#### 3.2 Send an Email

Demonstration	Syntax	Expert Results
Set parameters of Email	AT+EMAILCID=1	OK
	AT+EMAILTO=30	OK
Set SMTP server address and port	AT+SMTPSRV="mail.sim.com",25	OK
Set user name and password	AT+SMTPAUTH=1,"john","123456"	OK
Set sender address and name	AT+SMTPFROM="john@sim.com", "john"	OK
Set the recipient(To:)	AT+SMTPRCPT=0,0,"john@sim.com","john"	OK

Set the recipient(Cc:)	AT+SMTPRCPT=1,0,"john@sim.com","john"	OK
Set the recipient(Bcc:)	AT+SMTPRCPT=2,0,"john@sim.com","john"	OK
Set the subject	AT+SMTPSUB="Test"	OK
Set the body	AT+SMTPBODY >This is a new Email	OK
Send the Email	AT+SMTPSEND	OK +SMTPSEND: 1

### 3.3 Send an Email with an attachment

Demonstration	Syntax	Expert Results
Set parameters of Email	AT+EMAILCID=1	OK
	AT+EMAILTO=30	OK
Set SMTP server address and port	AT+SMTPSRV="mail.sim.com",25	OK
Set user name and password	AT+SMTPAUTH=1,"john","123456"	OK
Set sender address and name	AT+SMTPFROM="john@sim.com" , "john"	OK
Set the recipient (To:)	AT+SMTPRCPT=0,0,"john@sim.com","john"	OK
Set the recipient (Cc:)	AT+SMTPRCPT=1,0,"john@sim.com","john"	OK
Set the recipient (Bcc:)	AT+SMTPRCPT=2,0,"john@sim.com","john"	OK
Set the subject	AT+SMTPSUB="Test"	OK
Set the body	AT+SMTPBODY >This is a new Email	OK
Set the attachment	AT+SMTPFILE=1,"test.txt",0	OK
Send the Email	AT+SMTPSEND	OK

URC indicates that the attachment may be send.1360 is the max length of data which can be sent at a time. It depends on the network status.		+SMTPFT: 1,1360
SMTP client requests to send 100 bytes. Response will indicates that user must input 100 bytes for transferring now.	AT+SMTPFT=100	+SMTPFT: 2,100 ..... //Input data OK
URC indicates that more data can be sent		+SMTPFT: 1,1360
The attachment has been transferred completely.	AT+SMTPFT=0	OK
URC indicates that the entire email has been send successfully		+SMTPSEND: 1

### 3.4 Send a UTF-8 Email

Demonstration	Syntax	Expert Results
Set parameters of Email	AT+EMAILCID=1	OK
	AT+EMAILTO=30	OK
Set the mail charset	AT+SMTPCS="UTF-8"	OK
Set SMTP server address and port	AT+SMTPSRV="mail.sim.com",25	OK
Set user name and password	AT+SMTPAUTH=1,"john","123456"	OK
Set sender address and name	AT+SMTPFROM="john@sim.com", "john"	OK
Set the recipient(To:)	AT+SMTPRCPT=0,0,"john@sim.com","john"	OK
Set the recipient(Cc:)	AT+SMTPRCPT=1,0,"john@sim.com","john"	OK
Set the recipient(Bcc:)	AT+SMTPRCPT=2,0,"john@sim.com","john"	OK
Set the subject	AT+SMTPSUB="54455354"	OK
Set the body	AT+SMTPBODY >546869732069732061206E6577204	OK

	56D61696C	
Send the Email	AT+SMTPSEND	OK  +SMTPSEND: 1

### 3.5 Retrieve the Email

Demonstration	Syntax	Expert Results
Set parameters of Email	AT+EMAILCID=1  AT+EMAILTO=30	OK  OK
Set POP3 server and account	AT+POP3SRV="mail.sim.com","john","123456",110	OK
Log in POP3 server	AT+POP3IN	OK  +POP3IN: 1
Get Email number and total size	AT+POP3NUM	OK  +POP3NUM: 1,2,11124
Get the specific Email's size	AT+POP3LIST=1	OK  +POP3LIST: 1,1,5556
Retrieve the specific Email	AT+POP3CMD=4,1	OK  +POP3CMD: 1
Get the Email content	AT+POP3READ=1460  ...  AT+POP3READ=1460	+POP3READ: 1,1460  +OK  ...  OK  +POP3READ: 1,1460  +OK  ...  OK
The Email's content is read completely	AT+POP3READ=1460	+POP3READ: 2,1183  +OK  ...

		OK
Log out POP3 SERVER	AT+POP3OUT	OK
		+POP3OUT: 1

### 3.6 Delete the Email

Demonstration	Syntax	Expert Results
Set parameters of Email	AT+EMAILCID=1	OK
	AT+EMAILTO=30	OK
Set POP3 server and account	AT+POP3SRV="mail.sim.com","john","123456",110	OK
Log in POP3 server	AT+POP3IN	OK
		+POP3IN: 1
Get Email number and total size	AT+POP3NUM	OK
		+POP3NUM: 1,2,11124
Mark the Email to delete	AT+POP3DEL=1	OK
		+POP3DEL: 1
Log out POP3 SERVER	AT+POP3OUT	OK
		+POP3OUT: 1

### 3.7 Get the Email's size and unique-id

Demonstration	Syntax	Expert Results
Set parameters of Email	AT+EMAILCID=1	OK
	AT+EMAILTO=30	OK
Set POP3 server and account	AT+POP3SRV="mail.sim.com","john","123456",110	OK

Log in POP3 server	AT+POP3IN	OK  +POP3IN: 1
Get Email number and total size	AT+POP3NUM	OK  +POP3NUM: 1,2,35797
Get the specific Email's size	AT+POP3LIST=1	OK  +POP3LIST: 1,1,16601
Get the specific Email's unique-id	AT+POP3UIDL=1	OK  +POP3UIDL: 1,1, AAAFOpdC AAAv60+tksFqRqk3/6ogog+g
Log out POP3 SERVER	AT+POP3OUT	OK  +POP3OUT: 1

**Contact us:**

**Shanghai SIMCom Wireless Solutions Ltd**

Addr: Building A, SIM Technology Building, No.633, Jinzhong Road, Changning Disdrict, Shanghai P.R. China 200355

Tel: +86 21 3252 3300

Fax: +86 21 3252 3301

URL: [www.sim.com/wm](http://www.sim.com/wm)